







SMRHS – CHEAT SHEET

11/18/06

Control Buttons - Model T5500 and T5550



Setting up your radio for the first time:

1. Plug in the accessory headset prior to powering up.
2. Hold the (+) key down and turn on the power – this turns off the “Roger” tone function. You should see this icon disappear off your display 
3. When you first turn on the radio with a headset attached, the icon for VOX (voice activated transmission) will appear – key the radio once (PTT) to clear this off. You will need to do this each time you turn your radio back on. 
4. Hold down the MENU key until large number flashes – set this to 14 by pressing (+) or (-) keys.
5. Press MENU key until small number flashes – set this to 1 by pressing (+) or (-) keys.
6. Press MENU key until “1^{CA}” shows (number may be different) – set to “0” by pressing (+) or (-) keys.
7. Press MENU key until  icon appears, set to “3” by pressing (+) or (-) keys.
8. Press MENU key until “QT” shows, set to “_”, by pressing (+) or (-) keys.
9. Hold MENU button down until the lock symbol appears 